

For the installation, maintenance and cleaning of the device, you must absolutely observe the relevant regulations and stipulations on explosion protection (VDE 0160, VDE 0165 or EN 60079-14) as well as the occupational safety provisions. The device was constructed acc. to standards:

AX12: EN60079-0:2012+A11:2013,
EN60079-11:2012, EN60079-26:2015
AX17: EN60079-0:2009, EN60079-1:2007

This operating manual is part of the device, must be kept near its location, always accessible to all employees.

This operating manual is copyrighted. The contents of this operating manual reflect the version available at the time of printing. It has been issued to our best knowledge. However, BD SENSORS is not liable for any incorrect statements and their effects.

– Technical modifications reserved –

1.2 Symbols used

- ⚠ DANGER! – dangerous situation, which may result in death or serious injuries
- ⚠ WARNING! – potentially dangerous situation, which may result in death or serious injuries
- ⚠ CAUTION! – potentially dangerous situation, which may result in minor injuries
- ! CAUTION! – potentially dangerous situation, which may result in physical damage
- 🔧 NOTE – tips and information to ensure a failure free operation

1.3 Target group


- ⚠ WARNING! To avoid operator hazards and damages of the device, the following instructions have to be worked out by qualified technical personnel.

1.4 Limitation of liability

By non-observance of the operating manual, inappropriate use, modification or damage, no liability is assumed, and warranty claims will be excluded.

1.5 Intended use

The **Differential Pressure Transmitter XMD** has been especially designed for the process industry and can be used for level measurement of closed, pressurized tanks, pump or filter controlling, etc. The transmitter is as a standard equipped with HART®-communication and the parameterization can be done via PC, HART®-communicator, etc.

This operating manual applies to devices with explosion protection approval and is intended for the use in IS-areas. A device has an explosion protection approval if this has been specified in the purchase order and confirmed in our order confirmation. In addition, the manufacturing label contains the -symbol.

It is the operator's responsibility to check and verify the suitability of the device for the intended application. In addition, it has to be ensured, that the medium is compatible with the media wetted parts. If any doubts remain, please contact our sales department in order to ensure proper usage. BD SENSORS is not liable for any incorrect selections and their effects!

The technical data listed in the current data sheet are engaging and must be complied with. If the data sheet is not available, please order or download it from our homepage. (<http://www.bdsensors.com>)

- ⚠ WARNING! Danger through improper usage!

1.6 Safety technical maximum values

1.6.1 Intrinsically safe version

AX 12-XMD: IBEXU 05 ATEX 1106 X

application in zone 1: II 1/2G Ex ia IIB T4 Ga/Gb
permissible temperatures for environment: -40 ... 70 °C
supply and signal circuit:

$U_i = 28 \text{ V}$, $I_i = 98 \text{ mA}$, $P_i = 680 \text{ mW}$, $C_i \approx 0 \text{ nF}$, $L_i \approx 0 \text{ }\mu\text{H}$
plus cable inductivity 1 $\mu\text{H/m}$ and cable capacity 160 pF/m (for cable by factory)

The internal capacity of supply connections compared to the housing is max. 27 nF

- 🔧 NOTE - The limit values are valid only for the devices with own-sure circuits!

1.6.2 Flameproof enclosure

AX 17-XMD: IBEXU 12 ATEX 1045 X

zone 1: II 2G Ex d IIC T5 Gb
permissible temperatures: -20 ... 70 °C

- 🔧 NOTE – The use of the devices with flameproof enclosure is not allowed in the areas of dust!

1.7 Package contents

Please verify that all listed parts are included in the delivery and check for consistency specified in your order:

- differential pressure transmitter
- protective cap
- this operating manual

2. Product identification

The device can be identified by its manufacturing label. It provides the most important data. By the ordering code the product can be clearly identified.




Fig. 1 manufacturing labels

- ! The manufacturing label must not be removed from the device!

3. Mechanical installation

3.1 Mounting and safety instructions

- ⚠ WARNING! Install the device only when depressurized and currentless!

- ⚠ WARNING! This device may only be installed by qualified technical personnel who has read and understood the operating manual!

- ⚠ DANGER! Caused by the explosion hazard following instructions have to be complied with:

The technical data listed in the EC type-examination certificate are engaging. If the certificate is not available, please order or download it from our homepage: <http://www.bdsensors.com>

Working on supplied (active) parts, except for intrinsically safe circuits, is principally prohibited during an explosion hazard.

Make sure that an equipotential bonding is in place for the entire course of the line, both inside and outside the intrinsic area.

In case of increased danger of lightning strike or damage by overvoltage, a stronger lightning protection should be planned.

Observe the limiting values specified in the EC type-examination certificate. (Capacitance and inductance of the connection cable are not included in the values.)

Make sure that the entire interconnection of intrinsically safe components remains intrinsically safe. The operator is responsible for the intrinsic safety of the overall system (installation of intrinsic parts).

Do not mount the device in a pneumatic flow rate!

Excessive dust deposits (over 5 mm) and a complete dust covering must be avoided!

When installing the device, at least the ingress protection IP 20 must be realised.

- ! Handle this high-sensitive electronic precision measuring device with care, both in packed and unpacked condition!

! There are no modifications/changes to be made on the device.

! Do not throw the package/device!

! To avoid damaging the diaphragm, remove packaging and protective cap directly before starting assembly. The delivered protective cap has to be stored!

! Place the protective cap on the pressure port again immediately after disassembling.

! Handle the unprotected diaphragm very carefully - it is very sensitive and may be easily damaged.

! Do not use any force when installing the device to prevent damage of the device and the plant!

! For installations outdoor and in damp areas following these instructions:

- Please note that your application does not show a dew point, which causes condensation and can damage the pressure transmitter. There are specially protected pressure transmitters for these operating conditions. Please contact us in such case.
- To prevent moisture admission in the plug the device should be installed electrically after mounting, at once. Otherwise a moisture admission has to be blocked e.g. by using a suitable protection cap. (The ingress protection in the data sheet is valid for the connected device.)
- Choose an assembly position, which allows the flow-off of splashed water and condensation. Avoid permanent fluid at sealing surfaces!
- When using a device with cable outlet, turn the outgoing cable downwards. If the cable has to be turned upwards, then point it downward so the moisture can drain.
- Install the device in such a way that it is protected from direct solar irradiation. Direct solar irradiation can lead to the permissible operating temperature being overstepped in the worst case. This is prohibited for applications in IS-areas!

- 🔧 When installing the device to the pressurized system, the operator has to ensure the correct sealing.

- 🔧 Check the intended resp. delivered seal for compatibility with the medium. If there is no compatibility, take a suitable seal.

- 🔧 Take note that no inadmissibly high mechanical stresses occur at the pressure port as a result of the installation, since this may cause a shifting of the characteristic curve or to the damage. This is especially important for very small pressure ranges as well as for devices with a pressure port made of plastic.

- 🔧 In hydraulic systems, position the device in such a way that the pressure port points upward (ventilation).

- 🔧 Provide a cooling line when using the device in steam piping.

- 🔧 If there is any danger of damage by lightning or overpressure when the device is installed outdoor, we suggest putting a sufficiently dimensioned overpressure protection between the supply or switch cabinet and the device.

3.2 General installation steps

- Carefully remove the pressure measuring device from the package and dispose of the package properly.
- Go ahead as detailed in the specific instructions below. Therefore, you will have to observe that:
 - the higher pressure must be connected with input "H"
 - the lower pressure must be connected with input "L"

3.3 Installation steps for NPT connections

- Use a suitable seal (e. g. a PTFE-strip).
- Screw the device into the corresponding thread by hand.
- Tighten it with a wrench (for 1/2" NPT: approx. 70 Nm).
- **The indicated tightening torques must not be exceeded!**

3.4 Positioning of the display and operating module

The display and operating module is continuously rotatable so that clear readability is guaranteed even in unusual installation positions. To change the position, go ahead as follows:

- Screw off the metal cap by hand.
- Turn the display and operating module carefully into the desired position by hand. The module is equipped with a rotational limiter.
- Before screwing on the cap again, the o-ring and sealing surfaces of the housing have to be checked for damage and if necessary have to be changed!
- Afterwards screw the metal cap on by hand and make sure that the housing is firmly locked again.

- ⚠ WARNING! It is prohibited to open and configure the devices in the presence of explosion hazards. Therefore, it is recommended to position the display and operating module together with the mechanical installation.

! Pay attention that no moisture can enter the device. Moreover, the seals and the sealing surfaces should not get dirty, as this may cause a reduction of the degree of protection depending on the case of application or place of installation. This can lead to a breakdown of the devices or to irreparable damages on the device.

4. HART® communication

- ⚠ DANGER! It is prohibited to interrupt the intrinsically safe circuit in the presence of explosion hazards in order to loop in a HART® communication interface (HART®-communicator or HART®-modem).

The analogue output signal is overridden by an additional signal according to the HART®-specification. The device can be configured via a HART®-communication device. Therefore, we suggest our programming kit CIS 150 (available as accessory).

To ensure a trouble-free operation the following requirements must be fulfilled:

maximal cable length between device and power supply:

$$L_{\max} = \frac{65 \cdot 10^9}{R_V \cdot C_V} - \frac{40 \cdot 10^3}{C_V}$$

whereas L_{\max} : maximum length of cable in [m]
 R_V : resistance of the cable together with the load resistance in Ω
 C_V : capacity of the cable in [pF/m]

resistance R:

$$R = \frac{U - 12}{0,024} \Omega$$

whereas U: power supply in [V_{DC}]

The resistance must be at least 240 Ω .

5. Special regulations for IS-areas

5.1 Protection against electrostatic charge hazards

Different types of the device partially consist of chargeable plastic components. These are in particular coating of the housing as well as the plastic pressure port (optionally). A potential electrostatic charge presents the danger of spark generation and ignition. An electrostatic charge must therefore be absolutely prevented.

- 🔧 Generally, a shielded cable must be used.

- 🔧 Avoid friction on the plastic surfaces!

- 🔧 Do not clean the device dry! Use, for example, a damp cloth.

The following warning sign is, if applicable, attached to the device. It points once more to the hazard of electrostatic charging.




Fig. 2 warning sign

- ! The warning sign must not be removed from the device!

5.2 Overvoltage protection

If the device is used as electrical equipment of category 1 G, a suitable overvoltage protection device must be connected in series (attend the valid regulations for operating safety as well as EN60079-14).

5.3 Schematic circuit

The operation of an intrinsically safe transmitter in intrinsic safe areas requires special care when selecting the necessary Zener barrier or transmitter repeater devices to allow the utilization of the device's properties to the full extent.

The following diagram shows a typical arrangement of power supply, Zener barrier and pressure transmitter.




Fig. 3 circuit diagrams

- ! Please pay attention to item (17) of the type examination certificate, which stipulates special conditions for intrinsically safe operation.

5.4 Exemplary circuit description

The supply voltage of e. g. 24 V_{DC} provided by the power supply is led across the Zener barrier. The Zener barrier contains series resistances and Zener diodes as protective components. Subsequently, the operating voltage is applied to the device and, depending on the pressure a particular signal current will flow.

- ⚠ DANGER! When installing the intrinsically safe device as a zone-0-equipment, the supplying must be carried out by a power supply which must be galvanically insulated and which is not allowed to be grounded.

5.5 Functional selection criteria for Zener barriers and galvanic power supply

The minimum supply voltage $V_{S \min}$ of the device must not fall short since a correct function of the device can otherwise not be guaranteed. The minimum supply voltage has been defined in the respective product-specific data sheet under "Output signal / Supply".

When using a galvanically insulated amplifier with a linear bonding, please attend that the terminal voltage of the device will decrease like it does with a Zener barrier. Furthermore, it has to be attended that the supply of the device will also decrease with an optionally used signal amplifier.

5.6 Test criteria for the selection of the Zener barrier

In order not to fall below $V_{S \min}$, it is important to verify which minimum supply voltage is available at full level control of the device. Full level control, i. e. a maximum or nominal output signal (20 mA), can be reached by applying the maximum physical input signal (pressure).

The technical data of the barrier will usually provide the information needed for the selection of the Zener barrier. However, the value can also be calculated. If a maximum signal current of 0.02 A is assumed, then – according to Ohm's law – a particular voltage drop results on the series resistance of the Zener barrier.

This voltage drop is subtracted from the voltage of the power supply and as a result, the terminal voltage is obtained which is applied on the device at full level control. If this voltage is smaller than the minimum supply voltage, another barrier or a higher supply voltage should be chosen.

- 🔧 Please pay attention when choosing the barrier or the transmitter repeater because some supplied devices / Zener barriers are not suitable for HART® communication. Most manufacturers offer a device group especially developed for this application.

- 🔧 When selecting the ballasts, the maximum operating conditions according to the EC type-examination certificate must be observed. When assessing these, refer to their current data sheets to ensure that the entire interconnection of intrinsically safe components remains intrinsically safe.

6. Electrical Installation

- ⚠ WARNING! Install the device in currentless environments only!

- ⚠ WARNING! Install the connection for devices equipped with terminal clamps so that the separating spaces comply with the standard and the connecting lines cannot be loosened.

- ⚠ WARNING! For devices with flameproof enclosure, a M20x1.5 cable gland HSK-M-Ex-d / Metr. is prescribed; this is already pre-mounted. Technical data: cable diameter $\varnothing 10 \dots \varnothing 14 \text{ mm}$, width across flats: 24 mm, continuous operating temperature: -60 ... 105 °C, certificate: II 2G 1D Ex d IIC.

- ⚠ By devices with pressure flameproof enclosure a cable gland M20x1.5 with the name HSK-M-Ex-d is prescribed. This is already premounted.


- ⚠ DANGER! Danger of explosion when surpassing the maximum supply of 28 V_{DC}!

- 🔧 NOTE – The cap for the connection clamps and display can be opened only if a locking protection, headless screw with inside hexagonal, remove became. The screw is on the right side below the cap. After attach of the cap for display and for the connection clamps, the locking protection must be screwed again purely. Besides, the lubrication of the thread ways is not necessary.

- 🔧 NOTE - The cable gland by devices with flameproof enclosure is suitable only for the firm transfer!


Establish the electrical connection of the device according to the technical data shown on the manufacturing label, the following table and the wiring diagram.

Pin configuration:

Electrical connections	Terminal clamps in clamping chamber with cable gland M 20 x 1,5 (for cable \varnothing 5 up to 14 mm)
Supply +	+
Supply -	-
Test COM / Test-COM	TEST+ COM/TEST-COM
Shield	

Wiring diagram:

2-wire system (current) HART®



- ! Make sure that the supply corresponds to protection class III (protective insulation).

Operating Manual



Differential-Pressure Transmitter for Process Industry

AX12-XMD

AX17-XMD



www.bdsensors.com

Headquarters

BD SENSORS GmbH
BD-Sensors-Str. 1
D - 95199 Thierstein
Germany
Tel.: +49 (0) 9235-9811-0
Fax: +49 (0) 9235-9811-11

Eastern Europe

BD SENSORS s.r.o.
Hradištská 817
CZ - 687 08 Buchovice
Czech Republic
Tel.: +42 (0) 572-4110 11
Fax: +42 (0) 572-4114 97

Russia

BD SENSORS RUS
39a, Varshavskoe shosse
RU - Moscow 117105

Russia
Tel.: +7 (0) 95-380 1683
Fax: +7 (0) 95-380 1681

China

BD SENSORS China Co. Ltd.
Room B, 2nd Floor, Building 10,
No. 1188 Lianhang Rd.
201112 Shanghai,
China
Tel.: +86 (0) 21-51600 190
Fax: +86 (0) 21-33600 613

further agencies in:

EUROPE

- Belgium
- Denmark
- Finland
- France
- Great Britain
- Greece
- Italy
- Lithuania
- Luxemburg
- Netherlands
- Norway
- Poland
- Portugal

- Romania
- Sweden
- Switzerland
- Slovakia
- Spain
- Turkey
- UK
- Ukraine

AFRICA

- Egypt
- South Africa

ASIA

- India
- Israel
- Japan
- Kazakhstan
- Malaysia
- Singapore
- Taiwan
- Thailand
- Vietnam

AUSTRALIA

The addresses of our distribution partners are listed on our homepage www.bdsensors.com. It is possible to download data sheets, operating manuals, ordering codes and certificates, as well.

Table of contents

1. General information
2. Product identification
3. Mechanical installation
4. HART® communication
5. Special regulations for IS-areas
6. Electrical Installation
7. Initial start-up
8. Operation
9. Error handling
10. Placing out of service
11. Maintenance
12. Service / Repair
13. Disposal
14. Warranty conditions
15. Declaration of conformity / CE

1. General information

1.1 Information on the operating manual

This operating manual contains important information on proper usage of the device. Read this operating manual carefully before installing and starting up the pressure measuring device.

Adhere to the safety notes and operating instructions which are given in the operating manual. Additionally, applicable regulations regarding occupational safety, accident prevention as well as national installation standards and engineering rules must be complied with!

! For the installation of a device with cable outlet following bending radiuses have to be complied with:

- cable without ventilation tube:
 - static installation : 5-fold cable diameter
 - dynamic application: 10-fold cable diameter
- cable with ventilation tube:
 - static installation : 10-fold cable diameter
 - dynamic application: 20-fold cable diameter

! To install a device with terminal clamps, the cap has to be screwed off. If the device is equipped with a display and operating module, this has to be pulled out carefully. Put it as long as installing the device non-tensioned next to the housing. Next insert it again carefully and ensure that the cords are not turned or squeezed. Before screwing on the cap again, the o-ring and sealing surfaces of the housing have to be checked for damage and if necessary to be changed! Afterwards screw the metal cap on by hand and make sure that the field housing is firmly locked again.

! For a clear identification, the intrinsically safe cables are marked with light blue shrink tubing (over the cable insulation). If the cable has to be modified (e. g. shortened) and the marking at the cable end has been lost in the process, it must be restored (for example, by marking it again with light blue shrink tubing or an appropriate identification label).

⚠ For the electrical connection a shielded and twisted multicore cable has to be used.

7. Initial start-up

⚠ WARNING! Before start-up, the user has to check for proper installation and for any visible defects.

⚠ WARNING! The device can be started and operated by authorized personnel only, who have read and understood the operating manual!

⚠ WARNING! The device has to be used within the technical specifications, only (compare the data in the data sheet and the EC type-examination certificate)!

8. Operation

8.1 Display and operating module




Fig. 4 touch pad

A bargraph is shown in the display, indicating the current pressure input as percentage of the specified pressure range. The indication of the measured value as well as the configuration of the individual parameters occurs through a menu via the display. The individual functions can be set with the help of three miniature push buttons located under the metal cap. For devices of the XMD series with aluminium die cast case, additionally the possibility is given to operate via three push buttons (accessible from above). This is especially an advantage in IS-areas, caused by the fact that the device can be configured in situ without opening the operating and display module. Therefore, the metal plate (on the top side of the device), has to be folded backwards after loosening the right screw. The definition of the three buttons is: ▼, OK, ▲ (starting at the left side).

The menu system is a closed system allowing you to scroll both forward and backward through the individual set-up menus to navigate to the desired setting item. All settings are permanently stored in a Flash EPROM and therefore available even after disconnecting from the supply voltage.

⚠ WARNING! It is prohibited to open and configure the devices in the presence of explosion hazards. After configuration it must be ensured that the device is completely closed again outside the explosion hazard area.

! Pay attention that no moisture can enter the device during configuration. Moreover, the seals and the sealing surfaces should not get dirty, as this may cause a reduction of the degree of protection depending on the case of application or place of installation. This can lead to a breakdown of the device or to irreparable damages on the device. Right after configuration, the metal cap has to be screwed on again.

8.2 Structure of the menu system

Please note the "Supplementary sheet to operating manual for xjact ci, xlact i, XMP ci, XMP i, XMD".

- **▲-button:** with this button you move forward in the menu system or increase the displayed value; it will also lead you to the operating mode (beginning with menu item "1 DISPLAY")
- **▼-button:** with this button you move back in the menu system or decrease the displayed value; it will also lead you to the operating mode (beginning with menu item "5 SERVICE")
- **OK-button:** with this button menu items and set values have to be confirmed

execution of configuration:

- set the desired menu item by pushing the ▲- or ▼-button
- activate the set menu item by pushing the OK-button
- set the desired value or select one of the offered settings by using the ▲- or ▼-button
- store/confirm the set value/selected setting and exit the menu by pushing the OK-button

⚠ If a parameter is configurable by a value, each digit may be configured separately. That means after activating such a menu item (e. g. "2.3.1 OFFSET") by pushing the OK-button, the first digit of the currently set value will start to blink. Now scroll up or down to the desired digit via the ▼- or ▲-button and confirm it with the OK-button. After that, the next digit will start to blink. Configure it in the same way. In the menu items "2.3.1 OFFSET" and "2.3.2 FINALVAL", the decimal point will then start to blink, and it is also possible to change its position by using the ▼- or ▲-button. By confirming the position with the OK-button, the total value will be stored if permissible. If the value is out of range, an error message (e. g. Error 03) will appear in the display and the set value will not be stored.

If you intend to set a negative value, the first digit has to be configured with the ▼-button.

8.3 Menu list

1 DISPLAY	Display parameter
1.1 P _{max}	Maximum pressure display (high pressure) The maximum pressure that occurred during the measurement is shown on the display.
1.2 P _{min}	Minimum pressure display (low pressure) The minimum pressure that occurred during the measurement is shown on the display.
1.3 T _{max}	Maximum temperature display (high temperature) The maximum temperature that occurred during the measurement is shown on the display.
1.4 T _{min}	Minimum temperature display (low temperature) The minimum temperature that occurred during the measurement is shown on the display.
1.5 CLEAR	Delete the values 1.1-1.4 (P _{max} , P _{min} , T _{max} , T _{min})
1.6 INFO	Configuration of the display Assignment of the settable digits "1": 1st line: measured pressure 2nd set pressure unit "2": 1st line: Output signal 2nd line: mA "3": 1st line: measured temperature 2nd line: °C "4": 1st line: measured pressure 2nd line: Change between pressure unit / output signal in mA "5": 1st line: measured pressure 2nd line: Change between pressure unit / temperature in °C "6": 1st line: measured pressure 2nd line: Change between pressure unit / output signal in mA / temperature in °C
1.7 RETURN	Return to menu 1 DISPLAY
2 CALIB	Configuration of measuring range, display and output signal
2.1 ZERO	Zeroing the display The message "CONFIRM" appears on the display when selecting the subsidiary menu item with the OK button. By holding the OK button pressed for at least 2 seconds the zeroing is performed, and the message "CONFIRM" disappears from the display.
2.2 CAL REF	Adjusts the analogue output with pressure reference
2.2.1 OFFSET	Adjusts the starting value for the output signal After the reference pressure has been applied and accepted, selecting the subsidiary menu item with the OK button causes the message "CONFIRM" to appear on the display. By holding the OK button pressed for at least 2 seconds the applied pressure is specified as the starting value for the output signal (4 mA), and the message "CONFIRM" disappears from the display. The displayed value remains unchanged.
2.2.2 FINALVAL	Adjusts the end value for the output signal After the reference pressure has been applied and accepted, selecting the subsidiary menu item with the OK button causes the message "CONFIRM" to appear on the display. By holding the OK button pressed for at least 2 seconds the applied pressure is specified as the end value for the output signal (20 mA), and the message "CONFIRM" disappears from the display. The displayed value remains unchanged.
2.2.3 RETURN	Return to menu 2.2 CAL REF
2.3 ADJUST	Sets the measuring range and the zero point
2.3.1 OFFSET	Sets the starting value of the measuring range The ▲ and ▼ buttons allow you to define a starting value for the measuring range. The permitted input range is between 0 ... 90% of the original measuring range (turn down max. 1:10). 4 mA is output when the value that has been entered is reached.
2.3.2 FINALVAL	Sets the end value of the measuring range The ▲ and ▼ buttons allow you to define an end value for the measuring range. The permitted input range is between 10 ... 100% of the original measuring range (turn down max. 1:10). 20 mA is output when the value that has been entered is reached.
2.3.3 Z-CORR	Zero-point correction of the display and output signal The message "CONFIRM" appears on the display when selecting the subsidiary menu item with the OK button. By holding the OK button pressed for at least 2 seconds the applied pressure is specified as the starting value for the output signal (4 mA), and the display is zeroed. The message "CONFIRM" disappears from the display.
2.3.4 RETURN	Return to menu 2.2 CAL REF
2.4 RETURN	Return to menu 2 CALIB
3 SIGNAL	Signal parameters
3.1 FUNKTION	Function selection "LINEAR" (linear function) "2SQR" $y = \sqrt{x}$ "2SQR3POW" $y = \sqrt{x^3}$ "2SQR5POW" $y = \sqrt{x^5}$ } cut off 2 %
3.2 DENSITY	Input of the density settable range: 100 ... 9999 kg/m ³ Conversion is only applicable to the units [mFH], [cmFH] and [mmFH].
3.3 DAMP	Configuration of the damping settable range: 0 ... 100 s
3.4 SIMULAT	Simulation of the output signal settable range: any, for example: 3.7 ... 22 mA
3.5 RETURN	Return to menu 3 SIGNAL
4 SETTINGS	Basic settings
4.1 DISPLAY	Configuration of the display unit
4.1.1 UNIT P	Configuration of the unit for pressure Units: bar, mbar, g/cm ² , kg/cm ² , Pa, kPa, Torr, atm, mmWS (mm H2O), mmHg, PSI, mFH*, cmFH*, mmFH* The conversion of all pressure-related parameters is performed automatically. *Input of the density is required. (see 3.2)
4.1.2 UNIT T	Configuration of the unit for temperature Units: °C and °F
4.1.3 RETURN	Return to menu 4.1 DISPLAY
4.2 HART-ID	HART-ID (only to be set with HART® devices in multi-drop mode) Set the desired ID no. (between "0" and "15") and confirm this with the OK button. It is only necessary to configure this number if you want to operate the device in multi-drop mode (connection of a number of HART® devices). If the ID no. is set to "0", the multi-drop mode is deactivated, and the measurement transducer operates in analogue mode.
4.3 USER-L	Configuration of the user's security level For security reasons it is necessary to enter the password before configuring the security level. Confirm this with the OK button. The password is factory-set to "0000". Security levels: "0": the whole menu system is enabled "1": the following menu items are enabled: 1 Display, 3 Signal, 4.3 USER-L "2": the following menu items are enabled: 1 Display, 4.3 USER-L
4.4 PASSWORD	Configuration of the password For security reasons it is necessary to enter the previous password before configuration. Confirm this with the OK button. The password is factory-set to "0000". Then set the new password and confirm this with the OK button. ⚠ If you have forgotten your password, you can request the master password, which is fixed at manufacture, from BD SENSORS.
4.5 LANGUAGE	Selection of DE or EN as the user language
4.6 WPROTECT	Write protection (HART®-configuration) Setting YES: write protection is activated, transmission of the HART® commands to the storage location is not possible. Setting NO: write protection is deactivated.
4.7 RETURN	Return to menu 4 SETTINGS
5 SERVICE	Service
5.1 FACTORY	Reset to factory settings
5.2 ERR CURR	Definition of the current settable values: 21.6 mA or 3.8 mA; the selected error current is output in response to a malfunction in the electronics
5.3 TYPE	Display of the device type
5.4 SER-NO	Display of the set serial number
5.5 VERS	Display of the program version
5.6 RETURN	Return to menu 5 SERVICE
6 RETURN	Return to display mode

9. Error handling

9.1 Error messages

PASSED PARAMETER TOO SMALL	entered parameter value is too small
PASSED PARAMETER TOO LARGE	entered parameter value is too large
LOOP CURRENT NOT ACTIVE	loop current is not active (HART ID > 0, device works in Multidrop mode)
APPLIED PROCESS TOO LOW	applied process is too low
APPLIED PROCESS TOO HIGH	applied process is too high
LOWER RANGE VALUE TOO HIGH	lower range value (OFFSET) is too high
LOWER RANGE VALUE TOO LOW	lower range value (OFFSET) is too low
UPPER RANGE VALUE TOO HIGH	upper range value (FINALVAL) is too high
UPPER RANGE VALUE TOO LOW	upper range value (FINALVAL) is too low
SPAN TOO SMALL	span too small
DEVICE MALFUNCT	internal failure → please send the device to BD SENSORS for repair

9.2 More errors and possible corrections

Malfunction	Possible cause	Error detection / corrective
display does not work	falsely connected	inspect the connections
	line break	inspect all connecting lines of the device (including the connector plugs)
	defective energy supply	inspect the power supply and the applied supply voltage at the transmitter
no output signal	wrong connected	inspect the connection
	line break	inspect all line connections necessary to supply the device (including the connector plugs)
	defective amperemeter (signal input)	inspect the amperemeter (fine-wire fuse) or the analogue input of the PLC
analogue output signal too low	load resistance too high	verify the value of the load resistance
	supply voltage too low	verify the output voltage of the power supply
	defective energy supply	inspect the power supply and the applied supply voltage at the device
small shift of output signal	diaphragm is highly contaminated	careful cleaning with non-aggressive cleaning solution and a soft brush or sponge; incorrect cleaning can cause irreparable damages on diaphragm or seals
	diaphragm is calcified or coated with deposit	if possible it is recommended to send the device to BD SENSORS for decalcification or cleaning
large shift of output signal	diaphragm is damaged (caused by overpressure or manually)	check the diaphragm; if it is damaged, please send the device to BD SENSORS for repair
measured value (display and analogue output) deviates from the nominal value	high pressure / pressure peaks	a recalibrated or replaced of the pressure port by BD SENSORS is necessary
	mechanical damage to diaphragm	
constant output signal at 4 mA	wrong ID-number	ensure in the menu item "ID" that the set value for the ID-number is "0000"

If you detect an error, please try to eliminate it by using this table or send the device to our service address for repair.

⚠ DANGER! Working on supplied (active) parts, except for intrinsically safe circuits, is principally prohibited during an explosion hazard. Additionally, the operator is obligated to observe the information concerning operation and maintenance work on the warning signs possibly affixed to the device.

! Improper action and opening can damage the device. Therefore repairs on the device may only be executed by the manufacturer!

10. Placing out of service

⚠ WARNING! Disassemble the device only in current and pressure less condition! Check before disassembly, if it is necessary to drained off the media before dismantling!

⚠ WARNING! Depending on the medium, it may cause danger for the user. Comply therefore with adequate precautions for purification.

11. Maintenance

In principle, this device is maintenance-free. If desired, the housing of the device can be cleaned when switched of using a damp cloth and non-aggressive cleaning solutions.

With certain media, however, the diaphragm may be polluted or coated with deposit. It is recommended to define corresponding service intervals for control. After placing the device out of service correctly, the diaphragm can usually be cleaned carefully with a non-aggressive cleaning solution and a soft brush or sponge. If the diaphragm is calcified, it is recommended to send the device to BD SENSORS for decalcification. Please read therefore the chapter "Repair" below.

! A false cleaning of the device can cause an irreparable damage on the diaphragm. Therefore, never use pointed objects or pressured air for cleaning the diaphragm.

12. Service / Repair

12.1 Recalibration

During the life-time of a transmitter, the value of offset and span may shift. As a consequence, a deviating signal value in reference to the nominal pressure range starting point or end point may be transmitted. If one of these two phenomena occurs after prolonged use, a recalibration is recommended to ensure furthermore high accuracy.

12.2 Return

Before every return of your device, whether for recalibration, decalcification, modifications or repair, it has to be cleaned carefully and packed shatter-proofed. You have to enclose a notice of return with detailed defect description when sending the device. If your device came in contact with harmful substances, a declaration of decontamination is additionally required. Appropriate forms can be downloaded from our homepage www.bdsensors.com. Should you dispatch a device without a declaration of decontamination and if there are any doubts in our service department regarding the used medium, repair will not be started until an acceptable declaration is sent.

⚠ If the device came in contact with hazardous substances, certain precautions have to be complied with for purification!

13. Disposal

The device must be disposed of according to the European Directive 2012/19/EU (waste electrical and electronic equipment). It is prohibited to place electrical and electronic equipment in domestic refuse!

⚠ WARNING! Depending on the measuring medium, deposit on the device may cause danger for the user and the environment. Comply with adequate precautions for purification and dispose of it properly.

14. Warranty conditions

The warranty conditions are subject to the legal warranty period of 24 months from the date of delivery. In case of improper use, modifications of or damages to the device, we do not accept warranty claims. Damaged diaphragms will also not be accepted. Furthermore, defects due to normal wear are not subject to warranty services.

15. Declaration of conformity / CE

The delivered device fulfils all legal requirements. The applied directives, harmonised standards and documents are listed in the EC declaration of conformity, which is available online at: <http://www.bdsensors.com>. Additionally, the operational safety is confirmed by the CE sign on the manufacturing label.